



Roll-Cote™

BACKED IN BLACK

Introducing **Roll-Cote™** High-Performance Moisture-Vapor-Barrier Coating and Primer, formulated to reduce substrate moisture-vapor emissions and prime floors prior to the application of underlayments.

KEY FEATURES

- Unlimited moisture on glue-down hardwood flooring installations—no testing required!*
- Blocks alkalinity
- Can be used on both concrete and wood substrates*
- Single component
- Durable and low odor
- Formulated to be Red List Free
- California Department of Public Health (CDPH) compliant for VOCs
- Black color for great visual indication of coverage or traffic contamination



With **Roll-Cote™**, Bostik's got your back!

For more information, contact us at:
1-800-726-7845 | www.bostik.com/us

*See Roll-Cote™ technical data sheet for more information.
T000414_011922



Roll-Cote™ Quick Reference By Application Type

Type of Application	Primer or Prime Coat	Vapor Retarder	Moisture Vapor Barrier	
Application Tools	3/8" nap roller or split-tip broom	3/8" nap roller	3/8" nap roller	
Substrate Type	Concrete, Highly Porous Concrete	Plywood, High-Performance Subflooring Panels	Concrete	
Flooring / Adhesive Types	Self-leveling underlayments, floor patches, tile mortars, or prior to applications of Roll-Cote™	Glue-assist, Floating Floors, Click-together Floors	Self-leveling underlayments, floor patches, tile mortars, hardwood flooring adhesives, and resilient adhesives ³	
Dilution Ratio	1 to 1 (with water by volume)	Undiluted	Undiluted	
Working Time	2-4 hours	1-3 hours	1-3 hours	
Shelf Life	12 months	12 months	12 months	
Re-sealed Shelf Life	--	1 year	1 year	
Coats Required	One	One	One coat Required for 90% RH	Two coats Required for 99% RH
Dry Film Thickness	--	4.1 mils	4.1 mil	8.2 mil
Moisture Limit	--	Wood substrate <15% per NWFA guidelines ¹	Up to 90% RH ²	Up to 99% RH ²
Coverage	500-800 ft ² per gallon (of concentrate)	200 ft ² per gallon	200 ft ² per gallon	100 ft ² per gallon
Dry Time	30 minutes	30 minutes	First coat: 30 minutes, Second coat: 1 hour	
Install Surface Preparation	1 hour	<1 hour	2.5 hours	
Install Wood	--	1 hour	2.5 hours	
Install Resilient	--	1 hour ³	2.5 hour ³	
Install Tile	1 hour	<1 hour	2.5 hours	

Read and understand technical and safety data sheets prior to installation. ¹Moisture content of wood substrate must not exceed 15% per NWFA guidelines. ²See flooring types on technical data sheet. ³SLU or floor patch may be required for compatibility with resilient adhesives and to prevent telegraphing of substrate and surface imperfections. Contact Technical Service for more information.

For more information, contact us at:
1-800-726-7845 | www.bostik.com/us

