

Technical Data Sheet Multi Bond 30mL Blister

Description

Bostik Multi Bond is a general purpose solvent based Nitrile Rubber Adhesive. It is nearly clear in colour and will give excellent bonds that are both chemical and temperature resistant. It is packaged in a convenient aluminium tube for ease use.

Features

- Nearly clear in colour
- Quick bonding
- Easy to use
- Chemical and temperature resistant

Recommended Uses

- It has many household and industrial uses and is particularly suitable in bonding leather, metals, wood, canvas PVC and other plastics.
- It is widely used in the repair of toys, leather goods, furniture, upholstery, jewellery and in the handicraft making areas.
- This is an excellent product where quick bonding and a clear bond line is required especially in the DIY market.



Application Instructions

Surface Preparation

- Surfaces to be bonded must be dry, clean and free of grease.
- If surfaces are non porous, smooth and glossy, roughen with glass paper (preferably) or apply solvent suck as Acetone.

Application

As a two way dry stick:

Apply an even film onto both substrates, leave 5-10 minutes then join together with as much as possible taking care not to trap any air.

• As a one way wet stick:

• Usually this technique is employed when either one or both of substrates to be bonded are porous (e.g. fabrics, cardboard).

Clean Up

• Any wet or partially wet adhesive can be removed with scraping and Bostik Solvent 9901. Dried adhesive is best removed with a scraper or by sanding.



Multi Bond 30mL Blister

Properties

Base:	Nitrile Rubber/Resin Based	
	Solution	
Form:	Medium Liquid (Brushable)	
Viscosity:	2400 cps ± 200	
Colour:	Clear to translucent	
Solids Content:	27.5 ± 1%	
Solubility:	Approx. 0.88	

Storage & Shelf Life

A minimum of 12 months in original sealed packaging if stored under cover away from heat.

Health & Safety

- If working in an area with poor ventilation or in a confined area, recommend a mask be worn.
- Avoid contact with skin, eyes and avoid breathing in vapour.
- Use in a well-ventilated area.
- If swallowed contact a doctor or Poisons Information Australia phone 131126 and New Zealand 03 4747000.
- For more detailed information refer to Material Safety Data Sheet.
- In case of emergency, contact 1800 033 111.

FIRST AID

If skin contact occurs, wipe off excess and remove contaminated clothing. Wash affected area thoroughly with soap and water.

Packaging

30mL blister packaged aluminium tubes in box lots of 10. An industrial size packaging of 4L and 20L is also available and known as Bostik 1768.

Product Details

Item Number	Size	Colour	Pack
			Quantity
298050	30mL Tubes on Blister	Clear to	6
	Card	translucent	

Multi Bond 30mL Blister

The information in this Technical Data Sheet is intended for the assistance of purchasers and is of a general nature. It reflects the extent of our knowledge and experience of our products and is based on tests which we believe to be reliable. However, no guarantee of accuracy can be given due to the wide range of surfaces, environmental and field conditions and variations encountered in raw materials, manufacturing equipment and methods at the place where the work is performed. Some of these will be beyond our knowledge or control. We recommend purchasers carry out their own tests to determine the suitability of the product for their particular purposes.

ALL SALES ARE EXPRESSLY LIMITED TO THE TERMS AND CONDITIONS OF SALE OF BOSTIK AUSTRALIA PTY LTD

Head Office: Bostik Australia Pty Ltd, 51-71 High Street, Thomastown VIC 3074

A.B.N. 79 003 893 838

Phone: (03) 9279 9333 Fax: (03) 9261 4744
Phone Stationery: Freecall 1800 898 551

Product stationery.australia@bostik.com

Enquiries:



Product: Bostik Multi Bond 30mL Blister

Issue Date: September 2014

Issue No.: 3 Author: AV

Division: Consumer

Total Pages: 3